

Type R Sash Balance SPECIFICATION SHEET

Fix it yourself without removing the sash. It is easy to fix broken sash balances. Hardware and installation instructions included so that all you need is a screwdriver.

Installation Instructions


Step 1.

Cut the broken cord about 1/4 inch above the top of the sash and use a tack to hold the free end to the corner of the sash. Remove the old pulley, replace with new Pullman Sash Balance. Enlarge opening if required. With printing on the Balance right side up, drive in both screws. Pull the tape out of the Balance 2 ft. at a downward angle. Wedge a screwdriver up into the opening just underneath the tape to hold it in place.




Step 2.

Now insert the prong of the adapter downward through the loop on the end of the tape. Tape must be on the outside of the adapter - the side away from the sash. Be careful not to kink the tape. Next, hold the tape snugly against the adapter and slip the prong-end of the adapter with the tape attached down into the space between the old cord and the window jamb.



Step 3.

Now, squeezing the adapter against the cord and the sash as tightly as possible, screw it firmly to the top of the sash. Finally, take up the slack in the tape by pulling it, again away from the Balance, and while you hold it firmly, remove the wedge from the opening in the Balance. Then let the tape slowly back into the Balance and the job is complete.



Pullman sash balances are designed to give you years of noiseless, effortless window operation. Zinc coated steel housing will resist ordinary climatic conditions.

Information needed when ordering:


- Weight
- Height
- Width of sash.
- Order 2 balances per sash (4 balances per window).

To weigh sash: Place any ordinary household or bathroom scale on the sill and lower the sash until it's full weight is recorded.

Weight of sash in pounds	Balance #
5 to 7	3-R
7 to 9	4-R
9 to 11	5-R
11 to 13	6-R

If there is a choice, pick the lighter balance for bottom sash, the heavier balance for upper sash. If your windows weigh more than 13 lbs, call for information on additional sizes.

Dimensions	Type R
A	4 3/8"
B	15/16"
C	2 1/2"
E	2 5/8"
Tape Length	40"



Phone orders:

Customer Service Contact
Ilze Skellen 585-334-1350 (ext. 302)

Fax Orders:

585-359-4460

E-mail:

BalanceSales@pullmanmfg.com

Payment options include Visa, Mastercard, and P.O. with approved application.